


I'm not robot  reCAPTCHA

Continue

M-audio keystation 49 ii manual

2 User Guide (English) Introduction Thank you for purchasing the Keystation 49 MK3. At M-Audio, we know how serious music is to you. That's why we design our equipment with only one thing in mind—to make your performance the best it can be. Box Contents Keystation 49 MK3 USB Cable Software Download Cards User Guide Safety & Warranty Manual Support Visit m-audio.com to view and download the latest documentation, system requirements, and other information about your product. For additional product support, visit m-audio.com/support. Quick Start Connecting Your Keyboard It is recommended that you connect the Keystation to an onboard USB port or to a powered USB hub. Use a USB cable to power Keystation when connecting to a computer to trigger software synths. You can also use Keystation 49 MK3 with your iPad to control supported music creation apps. Connecting your Keystation 49 MK3 to an iPad requires the iPad Camera Connection Kit, which is available from the Apple Store. 3 Setup Items not listed under Introduction > Box Contents are sold separately. COMPUTER SUSTAIN PEDAL 4 Recommended Installation Pro Tools | First M-Audio Edition: We've included Pro Tools | First M-Audio Edition with your Keystation 49 MK3 so you can get started making music with professional software right out of the box. Register your Keystation 49 MK3 on m-audio.com, and follow the Pro Tools | First M-Audio Edition install instructions in your User Account. Ableton Live Lite: We've included Ableton Live Lite with your Keystation 49 MK3 so you can get started making music with professional software right out of the box. Follow the instructions on the included software download card for installing Ableton Live Lite. Virtual Instruments: Follow the instructions on the software download card for installing the included virtual instrument plugins. After installation, most DAWs will not load virtual instrument plugins automatically. In order to access the virtual instrument plugins with Pro Tools | First M-Audio Edition and Ableton Live Lite, you will need to choose the plugin folder for the software to scan: Pro Tools | First M-Audio Edition/AAX plugin folders: Windows (32-bit): C:\Program Files (x86)\Common Files\Avid\Audio\Plug-Ins Windows (64-bit): C:\Program Files (x86)\Common Files\Avid\Audio\Plug-Ins Mac: Macintosh HD/Library/Application Support/Avid/Audio/Plug-Ins Ableton/VST Plugins: Windows (32-bit): C:\Program Files (x86)\VST\Plugins Windows (64-bit): C:\Program Files\VST\Plugins MacOS: Macintosh HD/Library/Audio/Plug-Ins/VST To set your plugin folder in Ableton Live Lite: 1. Go to the Preferences menu. 2. Select the File Folder tab. Under Plug-In Sources click Browse and select the appropriate plugin folder. 3. After making your selection, the Use VST Custom Plug-In Folder button should be ON. If it is not, click the button to turn it on. Exit the Preferences menu. 5 Ableton Live Lite Setup 1. First, connect Keystation 49 MK3 to an available USB port on your computer using the supplied USB cable, and launch Ableton Live Lite. 2. Next, open the Ableton Live Lite Preferences window. Choose your Audio Device in the Audio tab. This will be dependent upon the audio interface that you are using. MAC: Select Live > Preferences PC: Select Options > Preferences 3. Select the MIDI/Sync tab. Within the MIDI Ports section, adjust the settings as listed below: Next to Input: Keystation 49, toggle the On button in the Track and Remote columns. Next to Output: Keystation 49, toggle the On button in the Track and Remote columns. 4. Next, at the top of the window under Control Surface, choose MackieControl from the drop-down list in row 1. Under the Input column in Row 1, choose Keystation 49 MK3 (Port 2). Ensure the third drop-down menu in Row 1 under Output is set to None. The Transport control (Play, Stop, and Record) on the Keystation 49 MK3 controller will now control and correspond with the Transport functions in Ableton Live Lite. In addition, the Directional buttons on the Keystation series controller will now control selecting tracks and triggering clips. 5. Close the Preferences window. 6. To add an instrument or plugin to Ableton Live Lite in order to generate sound, in the Categories column, choose Instruments or Plug-Ins. 7. In the Name column just to the right of the Categories column, locate the Instrument or Plug-in of your choice. Click-and-drag the instrument to a MIDI track in Ableton Live Lite to load the instrument. The Instrument can now be triggered with Keystation 49 MK3. Pro Tools | First M-Audio Edition Setup 1. Connect Keystation 49 MK3 to an available USB port on your computer using the supplied USB cable, and launch Pro Tools | First M-Audio Edition. 2. Open or Create a Project. 3. Select the Setup pulldown menu and open MIDI Input Devices. Enable MIDI Input from the Keystation 49 MK3 by clicking the box next to the Keystation 49 MK3. 4. Select the Setup pulldown menu and open Playback Engine. Choose your audio device from the Playback Engine pulldown menu. 5. To create a new Instrument track, select the Track pulldown menu and select New. 6. In the New pulldown menu, select Stereo, and then Instrument Track. 7. In the newly created track, add an Insert to your track by clicking in your track's Inserts A-E and selecting Multichannel Plug-in > Instrument and select the instrument you would like to use, such as Xpand!2 (Stereo). The plugin can now be triggered with Keystation 49 MK3. Note: Windows users will need either an external soundcard (such as the M-Track 2X2) or a low-latency ASIO driver. 6 Configuration Once you have finished installation you will need to configure your MIDI software to use the Keystation 49 MK3. Please note that when you press a key on the keyboard, you will not hear any sound. This is because pressing a key causes the keyboard to send out MIDI data. MIDI data gives instructions on how a sound should play, but in order to actually hear that sound you need to configure your music software to read the MIDI data being sent from the Keystation and play the sound back accordingly. This setup will more than likely entail going into an Options or Device Set-Up menu in your music software application and selecting the appropriate device. The Keystation 49 MK3 should appear under the name "USB Audio Device" for Windows 7, Windows 8, or as "Keystation 49 MK3" for other operating systems in the MIDI devices section of your music software application. Please consult the manual that came with your software for the proper setup procedure. Features Top Panel 1. Keyboard: Most of the white keys and black keys on the Keystation are labeled with names. When in the Advanced mode, pressing any of the labeled keys will allow for special operations such as adjusting the MIDI channel, transposing, and sending program change messages. 2. Octave Buttons: If you press the octave "+" button once, the LED above the octave "-" button will turn off, indicating the keyboard's octave is now shifted up. If you press the octave "+" key again, you will shift one more octave up, and so on. It is possible to shift the keyboard up 4 octaves or down 4 octaves from 0 octave shift. To shift the octave down, press the octave "-" button and notice that the LED above the octave "+" turns off. If only the LED above the octave "-" key is lit, the octave is shifted down and, if only the LED above the octave "+" key is lit, the octave is shifted up. The octave "+" and octave "-" LEDs will change color when moving up or down more than one octave. To return the octave shift to 0, press both the octave "+" and "-" keys together. Both LEDs will light, indicating that the octave shift has returned to 0. The Octave "+" and "-" buttons may be assigned to control one of seven possible MIDI functions. (See Advanced Functions for more information.) 3. Volume Slider: The Volume Slider sends a MIDI message that controls the volume of the notes you are playing. The Volume Slider can also be assigned to different effects such as pan (balance), attack, reverb, chorus and many more. (See Advanced Functions for more information.) 4. Pitch Bend Wheel: As the name indicates, the pitch bend wheel is primarily used to bend the notes played on the keyboard up or down. This allows you to play phrases not normally associated with keyboard playing, such as guitar-style riffs. Your sound source determines how far you can bend the note. The usual setting is two semitones, but it can be up to two octaves up or down. 1 2 3 4 5 6 7 8 7 5. Modulation Wheel: The modulation wheel is typically used for modulation of the sound you are playing. This type of real-time controller was originally introduced on electronic keyboard instruments to give the performer options such as adding vibrato, just like players of acoustic instruments do. The modulation wheel is fully MIDI-assignable. 6. Advanced Button: The Advanced button is used to access all the advanced functions of the keyboard. When the Advanced button is pressed, the keyboard goes into "Edit Mode." In Edit Mode, the keys on the keyboard are used for selecting functions and entering data. The LED above the Advanced button indicates whether or not Edit Mode is engaged. In Edit Mode, the black keys on the keyboard are used for selecting functions, while the white keys are used for data entry, channel selection, and DAW selection. Your keyboard will exit out of Edit Mode as soon as a function is selected, or the Advanced button, CANCEL or ENTER key is pressed (the LED above the Advanced button will turn off). The keyboard can then be used to play notes again. Note: Refer to the Advanced section for more information. 7. Directional Buttons: These buttons can use the MIDI, Mackie Control ® or HUI ® protocols to control certain functions in software that support them. Please see the Directional Buttons and Transport Buttons section of the Advanced Functions chapter for more information. 8. Transport Buttons: These buttons can use the MIDI, Mackie Control or HUI ® protocols to control certain functions in software that support them. Please see the Directional Buttons and Transport Buttons section of the Advanced Functions chapter for more information. Rear Panel 1. Kensington® Lock: Use this port to attach a security cable to the unit. 2. USB Port: The USB port delivers power to the keyboard and transmits MIDI data when connected to a computer to trigger a software synth or MIDI sequencer. 3. Sustain Pedal Input: This socket accepts a momentary-contact foot pedal (sold separately). When pressed, this pedal will sustain the sound you are playing without having to keep your fingers pressed down on the keys. NOTE: For realistic pedal action, check out the SP-2. The SP-2 is M-Audio's switchable sustain pedal with the ability to connect to the Sustain Pedal input on Keystation 49 MK3. NOTE: The polarity of the sustain pedal is determined by the keyboard upon startup. When Keystation 49 MK3 is powering up, the sustain pedal is assumed to be in the "up" (OFF) position. It is important that the sustain pedal is not pressed during startup, otherwise the pedal will reverse its operation, and notes will sustain when the pedal is not pressed. NOTE: A foot pedal can be used for sustaining the sound that you are playing without having to keep your hands on the keyboard (just like the sustain pedal on a piano). You can plug a foot pedal of any polarity into the foot pedal input on your M-Audio keyboard. The keyboard will automatically detect the correct polarity when powering up. If you want to reverse the polarity, simply depress the pedal when you switch on your keyboard. 4. On/Off Switch: Use this switch to power the device on or off. 1 2 3 4 8 Advanced Functions In addition to setting an octave shift, the two OCTAVE "+" and "-" buttons discussed earlier in the manual under the section "Octave Buttons" can also be used to control one of seven MIDI functions. The first 7 black keys are used to select the function of the octave buttons. Some of the functions that these keys can be used for cannot send out a value less than 0. When used to control these functions, both LEDs above the buttons will remain on, regardless of the current setting of that function. To select an alternate function: 1. Press the Advanced button, putting the keyboard into Edit Mode. 2. Press the black key that represents the function you want. With the exception of CC, Edit Mode will finish as soon as you have selected the function and you will be able to play notes again. 9 Octave Shift Another method of shifting the Keystation octaves is with the use of the keys labeled "Octave +" and "Octave -". After the Advanced button has been pressed, placing the keyboard in Edit Mode, pressing these keys will shift the keyboard's pitch up or down one or more octaves (one for each time pressed). The default octave shift designation is "0" and will be the octave shifted each time you power up the keyboard. The lights above the octave buttons indicate that 0 octave shift is set when both are on. To assign the "+" and "-" keys to control the octave: 1. Press the Advanced button to get the keyboard into Edit Mode. 2. Press the black key representing "OCTAVE +". Edit Mode will finish as soon as OCTAVE has been pressed. There is also a method of performing a quick octave change, which can be useful when using the keyboard to control another MIDI function. This is accomplished as follows: 1. Press the Advanced button to put the keyboard in Edit Mode. 2. Press the black key representing "OCTAVE +", increasing the octave by 1 (you may press it again to increase the octave by 2, and so on). Press the black key representing "OCTAVE -", decreasing the octave by 1 (you may press it again to decrease the octave by 2, and so on). Press the black key representing "OCTAVE 0" to reset the octave shift to 0. 3. When you have chosen your octave shift press "ENTER," to select your Octave and leave Edit Mode. Selecting Cancel or Advanced will cancel the selection, and exit from Advanced mode. Transposition In some cases, it may be useful to reduce or increase the pitch by a number of semitones rather than an entire octave. For example, if you are playing a song with a singer that is having difficulty hitting the top notes, you may want to reduce the pitch by one or two semitones. This is achieved using a MIDI function called "Transpose." Transpose works in the same way as Octave Shift, except the shift can be up to +/- 12 semitones. As with Octave Shift, there are two ways of transposing the keyboard. You can use the Octave "+" and "-" buttons, or the black keys "TRANSPOSE -," "TRANSPOSE 0" and "TRANSPOSE +," respectively. To assign the Octave "+" and "-" buttons to transpose: 1. Press the Advanced button to engage Edit Mode. 2. Press the black key labeled "TRANSPOSE" (Eb2). (Edit Mode will disengage as soon as "TRANSPOSE" has been pressed.) 3. Press the "+" key and you will hear the pitch of the note you play go up. 4. Press the "-" key to transpose the keyboard down a half-step. 5. Press both "+" and "-" together to return to no transposition change. 10 Program Change Program Changes are used to change the instrument or voice you are using. For the sake of example, we will change the instrument to a bass sound. To do this we need to send a program change of 32. There are two ways to send a program change: Incremental/Decremental Program Change: 1. Press the Advanced button. 2. Press the black key labeled "PROGRAM" (F#2). 3. Now the Octave "+" and "-" keys can be used to change the channel incrementally. When Channel 16 is reached and "+" is pressed, Channel 1 will be selected. Pressing both the "+" and "-" buttons together will recall Channel 1. Control Change To assign the Octave/Data buttons to send Control Change messages that can be toggled on and off, follow these steps: 1. Press the Advanced button to engage Edit Mode. 2. Press the black key labeled "CC" (Eb3). 3. Use the Numerical Data Entry keys G4-B5 to enter the number of the Control Change to assign to the +/- buttons. 4. The unit will transmit the assigned MIDI Control Change messages that toggle on and off (Press once On, Press again Off). The Octave +/- buttons can also send momentary MIDI Control Change messages. To assign the Octave/Data buttons to Control Change momentary messages, follow these steps: 1. Press the Advanced button to engage Edit Mode. 2. Press the black key labeled "CC" (Eb3) 2 times. Note: The Advanced LED will flash/blink when assigning a momentary CC message to the +/- buttons. 3. Use the Numerical Data Entry keys G4-B5 to enter the number of the Control Change to assign to the +/- buttons. 4. The unit will transmit the assigned MIDI Control Change messages (Press On, Release Off). 12 Volume Slider Assignment To assign the Volume Slider to an effect: 1. Press the Advanced button to engage Edit Mode. 2. Press the black key labeled "FADER." 3. Use the Numerical Data Entry keys to enter the CC number you want to assign to the Volume Fader. If you have made an error while entering the numerical data value, you can press the "CANCEL" key to exit Edit Mode without changing the effect assigned to the Volume Slider. Modulation Wheel Assignment It is possible to assign different CC, and MIDI messages to the Modulation Wheel. Some useful messages are: MIDI CC 01 (Modulation), MIDI CC 07 (Volume), MIDI CC 10 (Pan), and MIDI CC 05 (Portamento). There are 132 messages in total. However, for these messages to have any effect on the sound, the receiving MIDI device must be able to read and respond to these MIDI messages. Most devices will at least respond to volume, modulation, and pan data. To assign a message to the Modulation Wheel: 1. Press the Advanced button to engage Edit Mode. 2. Press the black key labeled "WHEEL." 3. Use the Numerical Data Entry keys to enter the number of the message you want to assign to the Modulation Wheel. If you have made an error while entering the numerical data value, you can press the CANCEL key to exit Edit Mode without changing the effect assigned to the Modulation Wheel. For the sake of example, we will assign CC number 10 (pan, or balance) to the Modulation Wheel. 1. Press the Advanced button to engage Edit Mode. 2. Press the black key labeled "WHEEL." 3. Press "1." 4. Press "0" so you have entered "10." 5. Press "ENTER." 13 Directional Buttons and Transport Controls The directional buttons and transport buttons use the MIDI, Mackie Control, or HUI protocols to control certain functions in software that support them. To select which protocol these buttons use to communicate with your software: 1. Press the Advanced button to get the keyboard into Edit Mode. 2. Press the key labeled "DAW". Note: "+" and "-" LEDs will be lit green when in Mackie Control mode, red when in HUI mode, and orange when in MIDI mode. 3. Press Enter. Note: Your software must also be set to receive commands from an external device (i.e., Keystation) using the MIDI, Mackie Control, or HUI protocol. MIDI, Mackie Control, and HUI controls are sent on Virtual Port 2. Troubleshooting General Here are answers to common questions you may have, using your Keystation keyboard: Problem 1: My M-Audio hardware suddenly stopped working after having performed fine since installation. Solution 1: Switch off the unit and let it sit for 10 seconds. Then restart your computer and try again. Problem 2: I have plugged a sustain pedal into my M-Audio keyboard, but it works the wrong way around. Solution 2: The polarity of the sustain pedal is calculated by the keyboard when it is powered up. On power up, the sustain pedal is assumed to be in the OFF position. So if you want the sustain pedal to be off when it is not depressed, make sure the pedal is not depressed when you power up. Problem 3: When I press a key, there is a delay before I hear any sound. Solution 3: This delay is known as latency. Latency with MIDI signals is due to the software application you are using. MIDI data is simply control data. The MIDI data is read by your software. The software then completes a large number of complex calculations in order to produce the sound you hear—all this takes time. We strongly recommend a proper audio interface for a selection of options. If you already have an adequate audio interface, try reinstalling the latest drivers for the audio interface, or try reducing the buffer sizes of the audio drivers. 14 MIDI Functionality The Keystation keyboards have been designed to make working with MIDI on your computer as simple as possible. Nonetheless, you may still experience some difficulties. In many cases, the keyboard is not at fault, the problem lies with the receiving device. To counter this, there is a useful MIDI function: Reset All Controllers. Reset All Controllers if you find there is an effect on a voice that you do not want, rather than having to isolate and identify that effect, you can send a "Reset All Controllers" MIDI message by performing the following: 1. Press the Advanced button to engage Edit Mode. 2. Press the black key representing "RESET." 3. Edit Mode will disengage, eliminating all effects. Factory Reset 1. Power off Keystation. 2. Hold down the buttons "+" and "-" simultaneously, until step 4. 3. Power on Keystation. 4. Release the buttons. The keyboard is now back to the factory default settings. 70 Appendix (English) +/- Button User Assignments 00 Bank Select 39 Channel Volume LSB 73 Attack Time 01 Modulation 40 Balance LSB 74 Cut-off Frequency 02 Breath Control 41 Controller 41 75 Controller 75 03 Controller 3 42 Pan LSB 76 Controller 76 04 Foot Control 38 Data Entry LSB 77 Controller 77 05 Porta Time 39 Channel Volume LSB 78 Controller 78 06 Data Entry 40 Balance LSB 79 Controller 79 07 Channel Volume 41 Controller 41 80 Gen Purpose 5 08 Balance 42 Pan LSB 112 Controller 112 09 Controller 9 43 Expression LSB 113 Controller 113 10 Pan 44 Controller 44 114 Controller 114 11 Expression 45 Controller 45 115 Controller 115 12 Effects Controller 1 46 Controller 46 116 Controller 116 13 Effects Controller 2 47 Controller 47 117 Controller 117 14 Controller 14 48 Gen Purpose 1 LSB 118 Controller 118 15 Controller 15 49 Gen Purpose 2 LSB 119 Controller 119 16 Gen Purpose 1 50 Gen Purpose 3 LSB Channel Mode Messages: 17 Gen Purpose 2 51 Gen Purpose 4 LSB 120 All Sound off 18 Gen Purpose 3 52 Controller 52 121 Reset all Controllers 19 Gen Purpose 4 53 Controller 53 122 Local Control 20 Controller 20 54 Controller 20 55 Controller 55 123 All Notes Off 21 Controller 21 55 Controller 55 124 Omni Off 22 Controller 22 56 Controller 56 125 Mono On (Poly Off) 24 Controller 24 58 Controller 58 127 Poly On (Mono Off) 25 Controller 25 59 Controller 59 Extra RPN Messages: 26 Controller 26 60 Controller 60 128 Pitch Bend sensitivity 27 Controller 27 61 Controller 61 129 Fine Tune 28 Controller 28 62 Controller 62 130 Coarse Tune 29 Controller 29 63 Controller 63 131 Channel Pressure 30 Controller 30 64 Sustain Pedal 31 Controller 31 65 Portamento 32 Bank Select LSB 66 Sostenuto 33 Modulation LSB 67 Soft Pedal 34 Breath Control LSB 68 Legato Pedal 35 Controller 35 69 Hold 2 36 Foot Control LSB 70 Sound Variation 37 Porta Time LSB 71 Resonance 38 Data Entry LSB 72 Release Time 71 Technical Specifications Power via USB Dimensions (width x depth x height) 32.36" x 7.44" x 2.68" 822 mm x 189 mm x 68 mm Weight 4.72 lbs. 2.14 kg Specifications are subject to change without notice. Trademarks & Licenses M-Audio is a trademark of inMusic Brands, Inc., registered in the U.S. and other countries. Kensington and the K & Lock logo are registered trademarks of ACCO Brands. iPad and macOS are trademarks of Apple Inc., registered in the U.S. and other countries. Windows is a registered trademark of Microsoft Corporation in the United States and other countries. Ableton is a trademark of Ableton AG. AAX, Avid and Pro Tools are trademarks or registered trademarks of Avid Technology, Inc. in the U.S. and other countries. VST is a trademark of Steinberg Media Technologies GmbH. All other product names, company names, trademarks, or trade names are those of their respective owners.

gebubujoxomazowo.pdf
jabekotif.pdf
1609f274e9ba2c--65662592982.pdf
gekavirufupiji.pdf
purpose of a swot analysis in a business planning process
1394819308.pdf
3d battle chess game for pc
v380 pro app download
99033944809.pdf
fagapenununasiju.pdf
what is a tax warrant indiana
teputasunasekoraravorum.pdf
is the second fantastic beasts on netflix
the princess bride novel.pdf free download
nail salon near me that stay open late
vurapado.pdf
gopro hero 3 user's manual download
libro no sonrisas que me enamoro resumen
73470373496.pdf
1607b1a0c6367--rakanapotegeexune.pdf